# Setting up MySQL on EC2

INF 551 Wensheng Wu

#### Install & start server

First, log into your EC2 instance

- Install MySQL (5.7) by executing the following command:
  - sudo yum install -y mysql57-server
- Start MySQL server:
  - sudo service mysqld start
  - (may want to restart the EC2 instance if this fails)

## Create root account of MySQL

- Execute this command: mysqladmin -u root password root
  - This will set password of root to be "root"

- If you already created a password and would like to change it to "root", then execute this:
  - mysqladmin -u root password root -p
  - When prompted, enter your old password

## Create/drop a database

- mysql -h localhost -u root -p
  - This will log you into MySQL
  - It may also work without "-h localhost"

MySQL statements end with;

- Once you log into mysql
  - create database inf551;
  - show databases;
  - exit
  - (drop database inf551; // in case you want to remove it)

### Create "beers" database

- Download script "beers-table.sql" (available on Blackboard in the same folder as this slide)
- Upload the script to your EC2 instance
  - E.g., using sftp
- Then execute (on the directory where the script is located):
  - mysql inf551 -u root -p < beers-tables.sql</li>

#### Create new user and database

- Login to MySQL as root
  - mysql -u root -p
- Create a new user 'inf551' with password 'inf551'
  - create user inf551@localhost identified by 'inf551';

- Create a database 'inf551' if you have not
  - create database inf551;

### **Grant permission**

- Grant all permissions on database 'inf551' to user 'inf551'
  - grant all privileges on inf551.\* to inf551@localhost;

- Login to the database 'inf551'
  - mysql inf551 -u inf551 -p